

## DOOR PANEL INSTRUCTIONS

### CUSTOM PANEL INSTRUCTIONS FOR BRILLIANCE MODELS SRN110, SRC065 & SRC035

A custom panel of wood or other material not exceeding 15 lbs. can be attached to the door. Attachment is from the ice side of the door. Holes are provided in the door for this purpose.

- Panel width: 14 7/8"
- Panel height: Between 29 3/8" and 30 3/8"
- Panel thickness: 5/8" to 3/4"

#### To create and attach a custom panel:

- 1 Measure overall height of cabinet opening where ice machine will be (floor to bottom of countertop edge).
- 2 Determine desired kickplate space (from bottom of door to floor). This could be equal to the adjacent cabinet's kickplate space or another space the user wants.
- 3 Subtract kickplate space from cabinet opening.
- 4 Subtract 1/8" or more for clearance space between top of door and bottom of countertop edge from cabinet opening. This is the maximum door length.
- 5 Cut panel to width.
- 6 Cut panel to length (cabinet space - kickplate space - top clearance = length).
- 7 Determine top of panel.
- 8 Mark hole locations using dimensions on the drawing on page 2 of these instructions. Drawing assumes top of panel will be flush with top of door. Measure hole locations from the top of the panel.
- 9 Drill pilot holes for wood screws. Use drill stop to prevent drilling through the panel.
- 10 Mount panel to door using wood screws or supplied panel mounting screws.

Note: When installed, ice machine must be adjusted for height to position top of door to desired clearance.

